




Earphones

with Remote and Mic

Congratulations on purchasing the Apple Earphones with Remote and Mic.

To use the Apple Earphones with Remote and Mic, plug them into a supported iPod, iPhone, or iPad and insert the earphones in your ears.



You can use the earphones with these models:

- iPod shuffle (3rd generation or later)
- iPod nano (4th generation or later)
- iPod classic (120GB and 160GB)
- iPod touch (2nd generation or later)
- iPhone 3GS
- iPhone 4
- iPad

Important: Not all features listed below are supported by all models. Check your product's user guide for more information.

To	Do this
Play or pause a song or video	Press the center button once. Press again to resume playback.
Skip to the next song or chapter	Press the center button twice quickly.
Fast-forward	Press the center button twice quickly and hold.
Go to the previous song or chapter	Press the center button three times quickly.
Rewind	Press the center button three times quickly and hold.
Answer or end a call	Press the center button once to answer. Press again to end the call.
Decline an incoming call	Hold down the center button for about two seconds, then let go. When you let go, two low beeps confirm that you declined the call.
Switch to an incoming or on-hold call and put the current call on hold	Press the center button once. Press again to switch back to the first call.

To	Do this
Switch to an incoming or on-hold call and end the current call	Hold down the center button for about two seconds, then let go. When you let go, two low beeps confirm that you ended the first call.
Increase volume	Press the + button.
Decrease volume	Press the – button.

Using VoiceOver

You can use VoiceOver on iPod shuffle (3rd generation or later) and iPod nano (5th generation or later) to announce the currently playing song title, artist name, and playlist, and to switch playlists.

To use VoiceOver, press the center button to hear the song title and artist name. Continue pressing until you hear a tone, then release the button. VoiceOver announces the current playlist, and then all your playlists. Press the center button when you hear the name of the playlist you want.

Important Safety Information

Avoid Hearing Damage

WARNING: Permanent hearing loss may occur if earphones are used at high volume. Set the volume to a safe level. You can adapt over time to a higher volume of sound that may sound normal but can be damaging to your hearing. If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the less time is required before your hearing could be affected. Hearing experts suggest that to protect your hearing:

- Limit the amount of time you use the earphones at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn down the volume if you can't hear people speaking near you.

For information about how to set a maximum volume limit, see the user guide for your iPod, iPhone, or iPad.

Keep Out of Reach of Children

WARNING: The small parts included with this product can be a choking hazard. This product is not intended for use by small children and should be kept away from children under 3 years of age.

Do Not Use While Driving

Important: Use of earphones while operating a vehicle is not recommended and is illegal in some areas. Check and obey the applicable laws and regulations on the use of earphones while operating a vehicle. Be careful and attentive while driving. Stop listening to your audio device if you find it disruptive or distracting while operating any type of vehicle or performing another activity that requires your full attention.

In Case of Skin Irritation

Earphones can lead to ear infections if not properly cleaned. Clean the earbuds frequently with an antiseptic, such as isopropyl alcohol. If a skin problem develops, discontinue use. If the problem persists, consult a physician.

More information about the Apple Earphones with Remote and Mic is available at:
www.apple.com/support

Avoid Electrostatic Shock

When using headphones in areas where the air is very dry, it is easy to build up static electricity and possible for your ear to receive a small electrostatic discharge from the headphones. To minimize the risks of electrostatic discharge from the headphones, avoid using the headphones in extremely dry environments, or touch a grounded unpainted metal object before inserting the headphones.