


## Quick-Start Guide: Logitech ClearChat Pro USB Headset



### Connecting and Using Your Headset

1. Plug the headset into an available USB port. Wait for Windows<sup>®</sup> to indicate that it has recognized the headset (a sound or pop-up window).
2. Put on the headset and rotate and bend the microphone into a position near the corner of your mouth.
3. Adjust volume controls (located on the right headphone) as desired. Pressing the volume ring on the **upper half** of the ring will **increase** the volume, pressing on the **lower half** will **decrease** the volume.
4. The **Logitech<sup>®</sup> logo on the right headphone is the microphone mute button**. When activated, the **RED** light on the microphone will illuminate to indicate the microphone is muted. Press the Logitech logo a second time to deactivate mute.
5. Equalizer Settings – Your headset has three Equalizer settings located on the right headphone that can instantly optimize audio performance for your activity.
  - ☎ — PC Calling
  - 🎮 — Gaming
  - 🎵 — Music/General Purpose

### Operation

The Logitech<sup>®</sup> ClearChat Pro USB<sup>™</sup> Headset works with any USB-compliant computer with the following operation systems: Windows<sup>®</sup> XP, Windows Vista<sup>™</sup>, Windows<sup>®</sup> 2000, Windows<sup>®</sup> Me, and Mac<sup>®</sup> OS X.

#### Windows<sup>®</sup> XP

1. Go to the START menu, choose CONTROL PANEL, choose SOUND AND AUDIO DEVICES
2. Choose the AUDIO tab, select the headset as the SOUND PLAYBACK and SOUND RECORDING device.
3. Choose the VOICE tab, select the headset as the VOICE PLAYBACK and VOICE RECORDING DEVICE.
4. Choose the VOLUME tab, adjust VOLUME SLIDER as necessary. The MUTE option should not be selected.

#### Windows Vista<sup>™</sup>

1. Go to the START menu, choose CONTROL PANEL, choose CLASSIC VIEW, choose SOUNDS.
2. Choose the PLAYBACK tab, select the headset as the SOUND PLAYBACK device. Choose PROPERTIES, choose the LEVELS tab, adjust the VOLUME SLIDER to desired level, verify the SPEAKER ICON is not muted.
3. Choose the RECORDING tab, select the headset as the SOUND RECORDING device. Choose PROPERTIES, choose the LEVELS tab, adjust the VOLUME SLIDER to desired level, verify the SPEAKER ICON is not muted.

#### Mac<sup>®</sup> OS X

1. Go to SYSTEM PREFERENCES, choose SOUND.
2. Choose the OUTPUT tab, select the headset as the SOUND OUTPUT device, adjust the OUTPUT VOLUME SLIDER to desired level, verify the MUTE box is unchecked.
3. Choose the INPUT tab, select the headset as the SOUND INPUT device, adjust the INPUT VOLUME SLIDER to desired level.

## Troubleshooting

**If the headset speakers are producing faint sounds or no sound, check the following:**

- Is the headset volume control (located on the right headphone) turned up?
- Is the headset configured as the active audio output device in the application you are using?
- Is the application you are using set to an audible volume level?
- Is your computer's sound control panel or system preference set to an audible volume level?

**If the microphone is not recording, check the following:**

- Is the headset microphone muted? (Logitech® logo on the right earpiece is the on/off switch).
- Is the headset configured as the active recording device in the application you are using? (You may have to restart the application after connecting the headset to your computer).
- Is your computer's sound control panel or system preference configured to record from the headset?
- Is the microphone positioned close to the corner of your mouth?

## Customer Service

If you need additional help with your product, contact Logitech® at (702) 269-3457 or on the web at [www.logitech.com/support](http://www.logitech.com/support).